



Samsung Gear Fit Watch Band Replacement

Replace the watch band on your Samsung Gear Fit.

Written By: Joel Ortiz



INTRODUCTION

The band is the easiest part to replace and requires no tools. Be careful as the watch may fling out of the band when popping it off.

Step 1 — Watch Band



- Place your thumbs on the ends of the screen.
- Push the watch outward while pulling the band away from the watch.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-27 04:11:39 PM.